



ROTARY HAMMER

40mm




ITEM NO. 2951

INSTRUCTION MANUAL

SPECIFICATION

Model	2951
Power	1500W
Voltage	220 V
Frequency	50 Hz
No-load Speed	100-590 RPM
Impact Energy	1-10 J
Max Impact Rate	800-4000BPM
Chuck Type	SDS-Max
Max Capacity in Concrete	40 mm
Net Weight	7.4KG
Includes	1set carbon brush 1pc auxiliary handle 1pc grease tube 1pc spanner 1pc SDS-MAX drill bit 16×280mm 1pc SDS-MAX drill bit 18×280mm 1pc point chisel 18×280

PART LIST**Product Elements**

- | | |
|-----------------------|---------------------------|
| 1. Switch Trigger | 5. Hammer mode selector |
| 2. Side handle | 6. Grease cover |
| 3. Bit holder | 7. Handle |
| 4. Bit release collar | 8. Variable speed control |

 NOTE!

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.



This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.



This sign means that there are important instructions of operation and handling in the manual that comes with this device.

GENERAL POWER TOOL SAFETY WARNINGS



WARNING!

Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tools or battery operated (cordless) power tool.

WORK AREA SAFETY

- ▷ Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- ▷ Don't operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- ▷ Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

ELECTRIC SAFETY

- ▷ Power tool plugs must match the outlet. Never modify the plug in any way. Don't use any adaptor plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- ▷ Avoid body contact with earthed or grounded surfaces such as pipe, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- ▷ Don't expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- ▷ Don't abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increased the risk of electric shock.

- ▶ When operating a power tool outdoors, use an extension cord suitable for outdoor use. Using a cord suitable for outdoor use will reduce the risk of electric shock.
- ▶ If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- ▶ Use of power supply via an RCD with a rated residual current of 30mA or less is always recommended.

PERSONAL SAFETY

- ▶ Stay alert, watch what you are doing and use common sense when operating a power tool. Don't use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- ▶ Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- ▶ Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energizing power tools that have the switch on invites accidents.
- ▶ Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- ▶ Don't overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- ▶ Dress properly. Don't wear loose clothing or jewelry. Keep your hair, clothing, and gloves away from moving parts. Loose cloths, jewelry or long hair can be caught in moving parts.
- ▶ If devices are provided for connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards. Collection can reduce dust-related hazards.

POWER TOOL USE AND CARE

- ▶ Don't force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- ▶ Don't use the power tool if the switch doesn't turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- ▶ Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- ▶ Store idle power tools out of the reach of children and don't allow persons unfamiliar with power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- Use the power tool, accessories and tool bits etc. in accordance with the instruction, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

SERVICE

- Have your power tool serviced by qualified repair person using only identical replacement parts. This will ensure that the safety of power tool is maintained.
- Follow instruction for lubricating and changing accessories.
- Keep handles dry, clean and free from oil and grease

GENERAL POWER TOOL SYMBOLS

Symbol	Name	Symbol	Name
V	Volts	SPM	Strokes per minute
A	Amperes	BPM	Beats per minute
Hz	Hertz	RPM	Revolutions per minute
W	Watts		Class II construction
Kg	Kilograms		Warning symbol
Min	Minutes		Earthing terminal
IPM	Impacts per minute		

ROTARY HAMMER SAFETY INSTRUCTIONS

- Wear safety goggles
- Wear ear protection.
- Wear dust mask
- Wear safety gloves
- Use auxiliary handle
- Use auxiliary handle, Loss of control can cause personal injury.

- ▶ Hold the power tool by insulated gripping surfaces, when performing an operation where the drilling or fasteners may contact hidden wiring or its own cord.
- ▶ Always start drilling at low speed and with the bit tip in contact with the workpiece. At higher speeds, the bit is likely to bend if allowed to rotate freely without contacting the workpiece, resulting in personal injury.
- ▶ Apply pressure only in direct line with the bit and do not apply excessive pressure. Bits can bend, causing breakage or loss of control, resulting in personal injury.

PREPARATION

WARNING!

- ▶ To prevent any accidents, assemble all parts of the Miter saw before connecting it to the power supply. The Miter saw shouldn't be connected to any power supply while you are assembling parts.
- ▶ If any parts are missing, do not operate this tool until the missing parts are replaced. Failure to do so could result in possible serious personal injury.

WARNING!

The machine is designed to be operated by one person. The prerequisites for operating the machine are physical and mental fitness as well as knowledge and understanding of the operating instructions. Persons who, due to their physical, sensory or mental capabilities, inexperience or lack of knowledge, are unable to operate the machine safely must not use the machine without supervision or instruction by a responsible person.

CAUTION!

To operate the Rotary Hammer, always use both hands at the same time and grab the device firmly.


ASSEMBLY

CAUTION!

Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.

AUXILIARY HANDLE


Loosen the auxiliary handle in the counter clockwise direction and adjust the handle to the desired working position. Then retighten the auxiliary handle by turning in the clockwise direction.



INSERTING TOOLS


The product is equipped with SDS-MAX attachment system for simple and convenient changing of tools without the use of additional tools.

- ▷ Clean and lightly grease the shank end of the tool before inserting.
- ▷ Pull back locking sleeve and hold.
- ▷ Insert the tool in a twisting manner into the tool holder until it latches itself.
- ▷ Check the latching by pulling the tool.



REMOVING THE TOOL

Push back the locking sleeve and remove the tool and store it safely.



WARNING!


Accessories can be hot after use. Don't touch the tip of accessory by hand! Please always use protective gloves to remove accessory.

WARNING!

Do not use tools without SDS-plus for hammer drilling! Tools without SOS-plus and their drill chucks are damaged by hammer drilling.


SWITCHING ON AND OFF

- ▶ To start the machine, press the ON/OFF trigger.
- ▶ To switch off the machine, release the ON/OFF trigger.



VARIABLE SPEED CONTROL

By turning the variable speed control, speed can be changed.



SETTING THE OPERATING MODE

The product can be switched to drilling, hammer and hammer/ drilling functions.



WARNING!

Change the operating mode only when the machine is switched off! Otherwise, the machine can be damaged.



Hammer and drilling mode

Drill in masonry, concrete and natural stone.



Hammer Mode

Chisel masonry, concrete and natural stone.



Releasing mode

Chisel rotation adjustment.

CHANGE CARBON BRUSHES

Check the carbon brushes after the first 50 hours of operation with a new machine or when new brushes are fit-ted. After carrying out the first check, repeat the check every 10 hours of operation. If the carbon is worn down to a length of 6 mm, or if the spring or contact wire is burnt or damaged, it is necessary to replace both brushes. If it turns out that the brushes can be used after removal, it is possible to re-mount them.

When servicing the carbon brushes, open the two locks, then remove the carbon brushes. Replace the carbon brushes in reverse order.

TROUBLESHOOTING

Trouble	Possible cause	Solution
Machine doesn't start	No power supply	Connect to mains
	Carbon brushes defect	change the carbon brush
	Motor defect	Contact the service team
	ON-OFF-switch defect	Contact the service team
Workpiece kick-back	poor drill point angle	Sharpen the drill
	poor chisel pointer	Sharpen the chisel

ENVIRONMENTAL PROTECTION

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and wellbeing. Disposal of discarded material shall be in accordance with local environmental regulations.

TOOL STORAGE AND MAINTENANCE

- ▶ Keep the device in dry and clean environment
- ▶ Always be sure that the tool is switched off and unplugged from power source before attempting to perform inspection or any maintenance.
- ▶ Never use gasoline, benzene, thinner, alcohol or the like. Discoloration, deformation or cracks may result.

عیب یابی

مشکل	علت احتمالی	راه حل
دستگاه روشن نمی‌شود	دستگاه برق ندارد	به منبع تغذیه وصل نمایید
	نقص در ذغال دستگاه	تعویض ذغال
	نقص در موتور	با مراکز خدمات تماس بگیرید
	نقص در کلید روشن و خاموش	با مراکز خدمات تماس بگیرید
پس زدن قطعه کار	کند شدن مته	تیز کردن مته
	کند شدن قلم	تیز کردن قلم

حفاظت از محیط زیست

ضایعات محصولات الکتریکی را نباید با زباله های خانگی دور ریخت. لطفاً به مراکزی که امکانات بازیافت وجود دارد تحویل داده شود. وسایل برقی را به عنوان زباله های شهری دور نریزید و مناطق مخصوص زباله های بازیافتی انبارش نمایید. برای کسب اطلاعات در مورد سیستم های جمع آوری زباله های بازیافتی با شهرداری منطقه خود تماس بگیرید. اگر وسایل برقی در محل های دفن زباله های معمولی دور ریخته شوند، امکان این وجود دارد که مواد خطرناک و سمی به سفره های زیرزمینی آب نشت کرده و وارد زنجیره غذایی شوند. که این امر موجب آسیب رسیدن به سلامت می شود. دفع ضایعات محصولات الکتریکی باید مطابق با مقررات محیط زیست باشد.

انبارش ابزار

همیشه قبل از انجام هر گونه بازرسی یا تعمیرات دستگاه را از منبع تغذیه جدا کرد و جهت انبارش در مکان خشک و بدون رطوبت نگهداری نمایید.

هرگز از گازوئیل، بنزن، تینر، الکل یا هر گونه مواد مشابه که خاصیت خوردگی دارند استفاده نکنید. چرا که موجب تغییر رنگ، تغییر شکل یا ترک خوردن دستگاه می شود.

کنزاکس سرویس


ضمن تشکر از حسن انتخاب شما

به همراه ابزار شما کارت ضمانت نامه ۱۲ ماهه کنزاکس سرویس ارائه می گردد.

لطفا توجه داشته باشید که هیچ کدام از اجزای داخلی ابزار، احتیاج به تعمیر و یا بهبود اضافه جهت بهینه نمودن عملکرد ندارند. بنابراین از هرگونه اعمال دستکاری یا مراجعه به مراکز تعمیرات غیر مجاز اجتناب نمایید و در صورت بروز هرگونه مشکل سریعاً با مراکز سرویس و پشتیبانی کنزاکس به شماره ۰۲۱-۶۲۸۱۹ و یا به وب سایت www.kenzax.com تماس حاصل نمایید.

سرعت متغییر (دیمر)

با چرخاندن دیمر می‌توان سرعت دستگاه را کاهش و یا افزایش داد.



تنظیم حالت چکشی ، سوراخکاری چکشی

دکمه خلاص کن کلید تغییر حالت عملکردی را فشار دهید و سپس با چرخاندن کلید ، علامت "C" را با یکی از نمادهای چکش، مته و چکش هم جهت کرده سپس دکمه را رها کنید تا حالت مورد نظر فعال شود.

حالت چکشی و سوراخکاری

برای سوراخکاری بر روی مصالح ساختمانی، سنگ و بتن.



حالت تخریب

برای تخریب مصالح ساختمانی، سنگ و بتن.



حالت خلاص کن

برای تنظیم زاویه نوک قلم



تعویض ذغال دستگاه

- ◀ ذغال‌های دستگاه را در ۵۰ ساعت اول کار با دستگاه و یا زمانی که ذغال‌های جدید نصب کرده‌اید بررسی کنید. سپس به ازای هر ۱۰ ساعت کار به طور دوره‌ای، ذغال دستگاه را بررسی نمایید.
- ◀ اگر طول ذغال به ۶ میلی‌متر کاهش پیدا کرده باشد و یا فنر یا سیم تعاسی سوخته یا آسیب دیده باشد، لازم است هر دو ذغال تعویض شوند.
- ◀ در صورتی که ذغال‌ها پس از بازرسی قابل استفاده بودند، امکان نصب مجدد آن‌ها بر روی دستگاه وجود دارد.




هشدار!

جهت بازدید و تعویض ذغال به نمایندگی‌های مجاز کنزاکس مراجعه نمایید.

جداسازی قلم و مته


روکش ابزارگیر را به سمت عقب کشیده سپس قلم/مته را از جای خود خارج نمایید.



لوازم جانبی ممکن است بعد از استفاده داغ شوند. نوک لوازم جانبی را با دست لمس نکنید! لطفا همیشه از دستکش های محافظ برای برداشتن لوازم جانبی استفاده کنید.


عملکرد سوئیچ روشن و خاموش

- ◀ برای راه اندازی دستگاه تنها کافیهست کلید روشن / خاموش را به سمت داخل فشار دهید تا دستگاه شروع به کار کند.
- ◀ بارها کردن کلید، دستگاه خاموش می شود.




دسته جانبی

دستگیره دسته جانبی را در جهت خلاف جهت عقربه‌های ساعت شل کنید و دسته را در زاویه دلخواه خود تنظیم کنید. سپس با چرخاندن دستگیره در جهت عقربه‌های ساعت، دسته جانبی را در زاویه دلخواه سفت کنید.



نصب قلم و مته

- ◀ این ابزار مجهز به سیستم ابزار گیر SDS-MAX (پنج شیار) می‌باشد ، از قلم و مته‌هایی استفاده نمایید که از این نوع سیستم پشتیبانی می‌کنند.
- ◀ قبل از انجام عملیات قسمت ابزار گیر و انتهای مته/قلم را کاملاً تمیز کرده و مقداری به گیریس آغشته نمایید.
- ◀ روکش ابزار گیر را به سمت عقب بکشید.
- ◀ مته/قلم را داخل ابزار گیر قرار دهید.
- ◀ روکش ابزار گیر را به سمت جلو هل دهید و از محکم بود ابزار داخل ابزارگیر اطمینان حاصل نمایید.



- ◀ از دسته جانبی تعبیه شده به همراه ابزار استفاده کنید. از دست دادن کنترل می‌تواند باعث آسیب شخصی شود.
- ◀ هنگام انجام عملیات سوراخ کاری در صورتی که ممکن است اجزای دستگاه با سیم کشی مخفی و یا قسمت‌هایی که احتمال وجود جریان برق در آن‌ها وجود دارد حتماً از قسمت‌های عایق شده دستگاه استفاده نمایید.
- ◀ همیشه در هنگام شروع عملیات سوراخ کاری سرعت دستگاه را در حالت کم نگه دارید. شروع حرکت در سرعت‌های بالا، احتمال شکستن و خم شدن مته را در زمان تماس با قطعه کار افزایش می‌دهد و منجر به ایجاد آسیب جسمانی می‌شود.
- ◀ تنها اعمال فشار به مته را در خط مستقیم وارد کنید. فشار بیش از حد می‌تواند موجب خم شدن و شکستن مته شود و منجر به ایجاد آسیب جسمانی می‌شود.

آماده سازی

هشدار!

۱. برای جلوگیری از هر گونه حادثه، قبل از اتصال دستگاه به برق، تمامی قسمت‌های دستگاه را مونتاژ کنید. در حین مونتاژ قطعات، دستگاه نباید به هیچ منبع تغذیه متصل شود.
۲. در صورت مفقود شدن قطعات دستگاه، از ابزار تا زمانی که قطعات گم شده تعویض و یا جایگزین نشده‌اند، کار نکنید. عدم انجام این کار می‌تواند منجر به صدمات جسمی جدی شود.

هشدار!

این دستگاه به گونه‌ای طراحی شده است که تنها توسط یک نفر کار کند. لازمه کار با دستگاه، آمادگی جسمانی و روحی و همچنین آگاهی و درک دستورالعمل‌های عملیاتی دستگاه می‌باشد. افرادی که به دلیل توانایی‌های جسمی، حسی یا ذهنی، عذک تجربه و یا عدم آگاهی قادر به کار ایمن با دستگاه نیستند، نباید بدون نظارت یا دستور شخص مسئول از دستگاه استفاده کنند.

احتیاط!

برای کار با بتن کن، همیشه از هر دو دست خود به طور همزمان استفاده کنید و دستگاه را محکم بگیرید.

نصب

احتیاط!

همیشه قبل از انجام هر گونه تغییرات بر روی ابزار، مطمئن شوید که ابزار خاموش بوده و از برق جدا شده باشد.

- ◀ از ابزارآلات برقی به خوبی نگهداری نمائید. هرگونه تنظیمات، گیرکردن قطعات دوار و یا هر وضعیت دیگری که ممکن است بر روی عملکرد دستگاه تاثیر بگذارد را بررسی نمائید و در صورت آسیب دیدگی قبل از استفاده، آن مورد را رفع نمائید. بیشتر حوادث از عدم نگهداری صحیح ابزارآلات برقی رخ می‌دهد.
- ◀ همواره از ابزار و لوازم جانبی مناسب این دستگاه استفاده نمائید. همچنین از این دستگاه تنها برای کارهایی که برای آن تهیه و طراحی شده است، استفاده نمائید.

تعمیرات و نگهداری

- ◀ برای هرگونه تعمیر و تعویض قطعات، تنها به مراکز خدمات پس از فروش **شرکت کنزاکس** مراجعه نمائید.
- ◀ برای انجام هرگونه روغن کاری و یا تعویض لوازم جانبی تنها از دستورالعمل‌های ذکر شده در منوال دستگاه پیروی نمایید.
- ◀ دستگاه‌های دستگاه را خشک، تمیز و عاری از هرگونه روغن و گریس نگه دارید.

نمادهای عمومی ابزار برقی

نماد	نام	نماد	نام
V	ولتاژ	SPM	کُرس بر دقیقه
A	آمپر	BPM	ضربه در دقیقه
Hz	هرتز (فرکانس)	RPM	دور بر دقیقه
W	وات (توان)		عایق دابل
Kg	کیلوگرم (وزن)		هشدار
Min	دقیقه		اتصال به زمین
IPM	ضربه در دقیقه		

دستورالعمل‌های ایمنی بتن کن

- ◀ از عینک ایمنی استفاده نمایید.
- ◀ از محافظ گوش استفاده نمایید.
- ◀ از ماسک گرد و غبار در هنگام کار استفاده نمایید.
- ◀ از دستکش ایمنی مناسب استفاده نمایید.
- ◀ از دسته جانبی استفاده کنید.

◀ هرگز ابزارهای دارای جریان متناوب را به منبع تغذیه برق با جریان غیرمتناوب (مستقیم) وصل ننمائید. این کار منجر به آسیب دیدگی دستگاه و آسیب های فردی خواهد شد.

ایمنی فردی

◀ زمانی که خسته اید یا تحت تاثیر دارو قرار دارید و در مجموع زمانی که در سلامتی کامل به سر نمی برید، هرگز از ابزارآلات برقی استفاده ننمائید. چرا که لحظه ای درنگ و بی دقتی منجر به صدمات جبران ناپذیری خواهد شد.

◀ همواره از لوازم ایمنی مانند عینک ایمنی، ماسک هوا، کفش و کلاه ایمنی و محافظ گوش استفاده ننمائید تا صدمات فردی کاهش یابد.

◀ برای اجتناب از شروع به کار ناگهانی دستگاه، قبل از اتصال آن به منبع برق از قرار داشتن کلید در وضعیت خاموش اطمینان حاصل ننمائید. همچنین زمانی که آن را جا به جا می کنید، دو شاخه را از پریز جدا کرده و انگشتان را بر روی کلید قرار ندهید.

◀ قبل از روشن کردن دستگاه از عدم اتصال هرگونه ابزار تنظیم مانند آچار به قطعات دوار اطمینان حاصل ننمائید چرا که می تواند منجر به صدمات جبران ناپذیری گردد.

◀ حالت صحیح قرارگیری پاها و حفظ تعادل بدن حین کار از خارج شدن کنترل دستگاه جلوگیری می نماید.

◀ همواره در حین کار از لباس کار مناسب استفاده ننمائید. استفاده از لباس های غیر استاندارد و گشاد، جواهرات و داشتن موهای بلند امکان درگیر شدن آن ها را با قسمت های متحرک ابزارآلات برقی افزایش داده و ممکن است خطر آفرین شود.

◀ در صورت استفاده از غبار جمع کن از اتصال صحیح و مناسب آن به دستگاه اطمینان حاصل ننمائید. استفاده از چنین لوازم جانبی، مضرات مربوط به غبارات را کاهش خواهد داد.

استفاده صحیح از دستگاه

◀ از اعمال بار اضافه به دستگاه جدا خودداری ننمائید. انتخاب درست ابزار برقی مناسب کارتان، باعث کاهش هزینه و زمان و حسن انجام کار برای شما خواهد شد. بنابراین همیشه برای انجام عملکرد مورد نظرتان از ابزار برقی مخصوص به آن کار استفاده ننمائید.

◀ در صورت معیوب بودن کلید دستگاه، هرگز از آن استفاده نکنید و به نزدیک ترین مراکز خدمات پس از فروش برای تعمیر آن مراجعه ننمائید. هر دستگاهی که با کلید قابل کنترل نباشد، خطر آفرین است و باید تعمیر شود.

◀ قبل از هرگونه تنظیم یا تعویض لوازم جانبی دستگاه، همچنین زمانی که از دستگاه استفاده نمی کنید دو شاخه را از منبع برق جدا ننمائید. این کار از شروع به کار ناگهانی دستگاه جلوگیری خواهد کرد.

◀ ابزارآلات برقی را از دسترس کودکان و افراد غیرمتخصص دور نگهدارید. ابزارآلات برقی در دسترس افراد آموزش ندیده، خطر آفرین خواهند بود.

دستورالعمل‌های کلی ابزارآلات برقی



هشدار !

لطفا کلیه مواردی که در ذیل قید شده است را با دقت مطالعه فرمائید و به کار برید، عدم پیروی از دستورالعمل‌های ذیل ممکن است منجر به ایجاد صدمات جبران ناپذیر فیزیکی یا ایجاد اختلال در کارکرد ابزارآلات برقی شوند.

این دفترچه راهنما را بعد از مطالعه نگهداری نمائید.

منظور از کلمه " ابزار برقی" در هشدارهای زیر کلیه ابزارهای برقی متصل به کابل یا ابزارهای شارژی دارای باتری می‌باشد.


ایمینی محل کار

- ◀ محل کار را تمیز و روشن نگهدارید. محیط‌های در هم ریخته و تاریک حادثه آفرین خواهند بود.
- ◀ هرگز از ابزارآلات برقی در مجاورت مواد اشتعال زا استفاده ننمائید. ابزار آلات برقی جرقه ایجاد می‌کنند که ممکن است موجب آتش سوزی گردد.
- ◀ ابزارآلات برقی را هنگام استفاده از دسترس کودکان و افراد غیرمتخصص دور نگهدارید. زیرا ممکن است باعث از دست دادن تمرکز و کنترل دستگاه شود.

ایمینی برقی

- ◀ دو شاخه دستگاه باید متناسب با پریز باشد. با این کار احتمال برق گرفتگی به شدت کاهش خواهد یافت.
- ◀ در هنگام استفاده از دستگاه به محل عبور لوله، کابل برق مربوط به رادیاتور، گرمخانه و یا یخچال و... توجه ننمائید. زیرا تماس بدن با آن‌ها احتمال خطر برق گرفتگی را افزایش می‌دهد.
- ◀ ابزارآلات برقی را در معرض باران و یا رطوبت قرار ندهید. ورود آب به ابزارآلات برقی ممکن است موجب برق گرفتگی شود.
- ◀ هرگز از کابل دستگاه برای حمل آن استفاده ننمائید و یا برای قطع اتصال دستگاه از پریز، کابل را نکشید. همچنین کابل را از معرض حرارت، سطوح نوک تیز، قطعات دوار و روغن دور نگهدارید. کابل‌های آسیب دیده مستعد بروز برق گرفتگی هستند.
- ◀ هنگام استفاده از دستگاه در محیط‌های باز، از سیم رابط مناسب استفاده ننمائید تا احتمال برق گرفتگی کاهش یابد.
- ◀ هنگام استفاده از دستگاه در محیط‌های مرطوب حتما از کلید حفاظت جان (RCD) برای اتصال دستگاه به منبع تغذیه برق شهری استفاده ننمائید. کلید حفاظت جان، مانند دستکش و کفش ایمنی به افزایش ایمنی فردی کمک می‌کند.

نام قطعات دستگاه



نام قطعات دستگاه

- | | |
|---------------------|---------------------------|
| ۱. سوئیچ روشن/خاموش | ۵. کلید تغییر حالت عملکرد |
| ۲. دسته جانبی | ۶. درپوش گریس |
| ۳. ابزارگیر SDS-MAX | ۷. دسته |
| ۴. روکش ابزارگیر | ۸. دیمر تغییر سرعت |

مشخصات فنی

مدل	2951
توان	۱۵۰۰ وات
ولتاژ	۲۲۰ ولت
فرکانس	۵۰ هرتز
حداکثر سرعت	۱۰۰-۵۹۰ دور بر دقیقه
انرژی ضربه	۱۰-۱ ژول
نرخ ضربه در حالت آزاد	۸۰۰-۴۰۰۰ ضربه در دقیقه
نوع ابزار گیر	SDS-Max (پنج شیار)
ظرفیت سوراخکاری	در بتن: ۴۰ میلی‌متر
وزن خالص	۷/۴ کیلو گرم

ذغال

دسته جانبی

گریس

آچار

مته ۲۸۰×۱۶ میلی‌متر

مته ۲۸۰×۱۸ میلی‌متر

قلم نوک تیز

متعلقات



بتن کن پنج شیار ۴۰ میلی متر



ITEM NO. 2951

دفترچه راهنمای فارسی